
## Atmosphyre


## Tub Filler Rough-in Installation

3310 Route 346 Pownal, Vermont 05261 802-949-7247

## INSTALLATION INSTRUCTIONS FLOOR MOUNT COMPLETE SET WITH QUICK CONNECT



WE RECOMMEND THAT ALL PLUMBING PRODUCTS
BE INSTALLED BY A LICENSED PROFESSIONAL



- Place the **QUICK CONNECT CYLINDER (1)** horizontally at the same level (SEE LABEL ON QUICK CONNECT FOR FINISHED FLOOR MIN. MAX LEVELS)
- Use screw or anchors to secure the **QUICK CONNECT** to the floor as shown in **FIG. 1** (Screws and anchors are not supplied)
- Take off CAPS (2) before connecting the FLEXIBLE HOSES (3) to the QUICK CONNECT (1)
- Connect the SPOUT (4) to the BODY (5) and fimly secure with the supplied SET SCREW (6)

**IMPORTANT:** Flush supply lines of all debris prior to connecting to faucet valve bodies. Debris remaining in the line will damage valve bodies and cause leaking. Failure to flush the lines could result in VOIDING the warranty